



PAR LED 18x1W RGB

Quicstart manual

1. menu functions

Display	Range	Function
d001	001-512	DMX address setup
CC00	00-99	Color snap
CP00	00-99	Color fade
dE00	00-99	Color change
bE00	00-99	Color change on sound
r255	000-255	Red
G255	000-255	Green
b255	000-255	Blue

2. DMX modes

7ch	Range	Function
1	000-255	Dimmer
2	000-001 002-255	Open Strobe (slow-fast)
3	000-050 051-100 101-150 151-200 201-255	DMX mode Color snap Color fade Color pulse Sound control mode (sensitivity low-high)
4	000-255	Function speed
5	000-255	Red
6	000-255	Green
7	000-255	Blue

3. Specification

Specification	
Power consumption	30 W
Supply voltage	110 - 240 V
Supply frequency	50 - 60 Hz
Diode type	Standard LED
Diode number	18 (6R 6G 6B)
Diode power	1W
Display	LCD
Control	4 buttons
Dimmer	Smooth 0-100%
DMX channels	7
Beam angle	25°
Control	DMX, Auto, Master/Slave, Sound
DMX IN	XLR
DMX OUT	XLR
Enclosure	ABS
Cooling	yes